

LISAKONSOLI – ASENNUSOHJE





Jokaisessa Lisakonsolissa on koukulla varustettu kierretanko, jonka pituus on sovitettu Lisan korkeuden mukaan.

Asennus:


1. Irrota yläritilä.
2. Kierrä mutteri ja aluslevy irti kierretangosta.
3. Laske kierretanko konvektorilevyjen väliin ja sen jälkeen konsolin reiän läpi.
4. Kiinnitä koukku konvektorilevyyn – katso kuva.
5. Asenna aluslevy ja mutteri ja kiristä.

HUOM! Älä kiristä mutteria niin tiukalle, että konvektorilevy taipuu.

6. Asenna yläritilä takaisin paikalleen.




LISA Floor Brackets




Brackets facing in one direction

LISA Floor Brackets



Brackets facing in one direction


LISA C-brackets



When two holes - use one far from the wall
Position two brackets towards each other


Lattia- ja seinäkonsolit ovat samanlaiset radiaattorin molemmissa päissä. C-konsolit asennetaan toisiaan kohti.

Seinä- ja C-konsoleissa on käytettävä kaikkia ruuvinreikiä, ja kiinnitystavan valitsee asentaja. Lattiakonsoli, jonka lattialevyssä on neljä ruuvinreikää, kiinnitetään vähintään kahdella ruuvilla ristikkäin, mutta luotettavan kiinnityksen varmistaminen on asentajan vastuulla. Ympäristö, rasitus sekä lattian ja seinän materiaali voivat vaikuttaa valintaan.



One threaded bar per bracket

Two threaded bars per bracket



Tyypeissä 44 ja 54 on kaksi kierretankoa

LISA BRACKET INSTALLATION MANUAL



Each Lisa Bracket is supplied with a Threaded Bar with hook, length according to Lisa height

Installation:

1. Remove the Top Grill off the radiator,
2. Untie the nut and washer off the threaded bar,
3. Put the Threaded Bar in between konvektors aiming the hole in the loop of bracket bottom,
4. Hook to the konvektor from above – see picture:
5. Put the Washer and tighten the Nut from below


Threaded Bar with Hook

Washer


Nut

Do not apply much force, as it will damage the konvektor

6. Put the Top Grill back onto radiator.




LISA Floor Brackets




Brackets facing in one direction

LISA Floor Brackets




Brackets facing in one direction

LISA C-brackets



When two holes - use one far from the wall
Position two brackets towards each other

Floor & Wall brackets are the same on both ends of the radiator. C-brackets face each other; two holes when needed
See proper position of the brackets for each radiator type below:



One threaded bar per bracket

Two threaded bars per bracket

